


PM-D600 / EPSON Stylus Photo R240/R245/R250

REV.01 C606-MECH-002



Part Code	Part Name	Ref No.	Category	Qty	Remark
1288281	INK CART.UNBOXED,B-SS,DYE;F11C,WST,AS	NONFIG	Accessories	1	
1288282	INK CART.UNBOXED,C-SS,DYE;F11C,WST,AS		Accessories	1	
1288283	INK CART.UNBOXED,M-SS,DYE;F11C,WST,AS		Accessories	1	
1288284	INK CART.UNBOXED,Y-SS,DYE;F11C,WST,AS		Accessories	1	
2068890	POWER CABLE		Accessories	1	
3100877	SOFTWARE CD,FIGD		Accessories	1	
3100879	SOFTWARE CD,EPRS		Accessories	1	
4103085	SETTING UP MANUAL		Accessories	1	
4103087	USER'S GUIDE		Accessories	1	
1410838	PAPER SUPPORT ASSY.	101	Case	1	
<u>1410785</u>	COVER,PRINTER;EFS2	102	Case	1	
1427131	HOUSING,UPPER;EDG2;B	103	Case	1	
1410783	HOUSING,LOWER;EDG2	104	Case	1	
1410796	COVER,INK TUBE;EDG2	105	Case	1	
<u>1108107</u>	FOOT	106	Case	4	
1410837	STACKER ASSY.	107	Case	1	
<u>1410837</u> <u>1410798</u>	LEVER,PG;EPG2	<u>107</u> <u>108</u>	Case	1	
<u>1410798</u> <u>1410793</u>	COVER,CARD SLOT;EDG2	109	Case	1	
1410793	LENS,CARD SLOT		Case	1	
	•	<u>110</u>		1	
<u>1410795</u>	COVER,PB;EDG2	111	Case		
<u>1410807</u>	GROUNDING PLATE, PANEL	112	Case	1 1	
1410797	COVER,USB;EDG2	113	Case	•	
1410305	LABEL,INK,POSITION	114	Case	1	
<u>1410805</u>	COVER,LCD	<u>120</u>	Case	1	
1410799	BUTTON, PANEL; EBCK	<u>121</u>	Case	1	
1410803	BUTTON, LENS, RIGHT	<u>122</u>	Case	1	
1410804	BUTTON,LENS,LEFT	<u>123</u>	Case	1	
<u>1410800</u>	BUTTON,SW;EBCK	<u>124</u>	Case	1	
<u>1410801</u>	BUTTON,SW,COPY UPPER;EBCK	<u>125</u>	Case	1	
1410802	BUTTON,SW,COPY LOWER;EBCK	<u>126</u>	Case	1	
<u>2103651</u>	HARNESS	<u>127</u>	Case	1	
<u>2104687</u>	LCD MODULE	<u>128</u>	Case	1	
<u>2103647</u>	BOARD ASSY.,PANEL	<u>129</u>	Case	1	
<u>1410806</u>	SHIELD PLATE, PANEL	<u>130</u>	Case	1	
<u>2109432</u>	BOARD ASSY.,MAIN	<u>200</u>	Electronic Parts	1	
<u>2103649</u>	HARNESS	<u>201</u>	Electronic Parts	1	
<u>1282387</u>	C.P.SCREW,3X4,F/ZN-3C	<u>202</u>	Electronic Parts	1	
1409444	SHIELD PLATE,M/B,UPPER	<u>203</u>	Electronic Parts	1	
<u>1409443</u>	SHIELD PLATE,M/B	<u>204</u>	Electronic Parts	1	
<u>1410835</u>	P/S BOARD ASSY.;220V	<u>300</u>	Electronic Parts	1	
<u>2106580</u>	PRINTER MECHANISM(ASP)MAK16-100	<u>500</u>	Mechanism Parts	1	
1409897	ASF UNIT	<u>501</u>	Mechanism Parts	1	
<u>1427156</u>	HOLDER,SHAFT ASSY.;B	<u>502</u>	Mechanism Parts	1	
2104560	BOARD ASSY.,DETECTOR	<u>503</u>	Mechanism Parts	1	
1295162	TORSION SPRING,137.7	<u>504</u>	Mechanism Parts	1	
2104179	MOTOR ASSY.,CR	<u>505</u>	Mechanism Parts	1	
<u>2103443</u>	CABLE,ENCODER,PF	<u>506</u>	Mechanism Parts	1	
2103145	BOARD ASSY.,ENCODER,PF;B	<u>507</u>	Mechanism Parts	1	
1408051	HOLDER,BOARD ASSY.,ENCODER,PF	<u>508</u>	Mechanism Parts	1	

1279686	LEVER,PARALLEL ADJUSTMENT,LEFT	<u>509</u>	Mechanism Parts	1
1279687	TORSION SPRING, SHAFT, CR, GUIDE	<u>510</u>	Mechanism Parts	1
1279683	LEVER,PARALLEL ADJUSTMENT,RIGHT	<u>511</u>	Mechanism Parts	1
1280780	PRESSING SPRING,SHAFT,CR,GUIDE	<u>512</u>	Mechanism Parts	1
1261564	EXTENSION SPRING,3.289	<u>513</u>	Mechanism Parts	1
1279691	SCALE,CR	<u>514</u>	Mechanism Parts	1
1410733	INK SYSTEM ASSY.	<u>515</u>	Mechanism Parts	1
1279688	SHAFT,CR GUIDE	<u>516</u>	Mechanism Parts	1
1420663	CR SUB ASSY.	<u>517</u>	Mechanism Parts	1
2103442	CABLE,HEAD	<u>—</u> 518	Mechanism Parts	1
1279690	TIMING BELT,CR	519	Mechanism Parts	1
2101872	BOARD ASSY.,ENCODER;C	<u>520</u>	Mechanism Parts	1
2109392	BOARD ASSY.,DETECTOR,PW	521	Mechanism Parts	1
1409448	COVER,CABLE,HEAD	522	Mechanism Parts	1
2088095	BOARD ASSY.,CSIC	<u>523</u>	Mechanism Parts	1
2060802	CONNECTER,CSIC	524	Mechanism Parts	4
1274963	TORSION SPRING, LEVER, CARTRIDGE; B	525	Mechanism Parts	1
1290662	GUIDE,IC	<u>526</u>	Mechanism Parts	1
F164030	PRINT HEAD	527	Mechanism Parts	1
1279681	COVER,FFC,SUB	<u>527</u> 528	Mechanism Parts	1
1409454	COVER,CARTRIDGE	529	Mechanism Parts	1
1409445	STAY,SHIELD PLATE,M/B	550	Mechanism Parts	1
1407753	FRAME, GUIDE, CR	<u>551</u>	Mechanism Parts	1
1280911	SCALE,PF;B	552	Mechanism Parts	1
1212722	DOUBLE SIDED TAPE,D21	553	Mechanism Parts	1
1261589	GROUNDING SPRING,PF	<u>554</u>	Mechanism Parts	1
1405516	ROLLER, PF ASSY.	555	Mechanism Parts	1
1409898	PAPER GUIDE, FRONT ASSY.	556	Mechanism Parts	1
1279708	POROUS PAD, PAPER GUIDE, FRONT	557	Mechanism Parts	1
2104175	MOTOR ASSY,,PF	558	Mechanism Parts	1
1279697	SPUR GEAR,30.8	559	Mechanism Parts	1
2104178	DETECTOR ASSYPG	<u>560</u>	Mechanism Parts	1
1405284	PAPER GUIDE, UPPER ASSY.	561	Mechanism Parts	3
1410916	STARWHEEL ASSY.	562	Mechanism Parts	1
1425018	ROLLER,EJ ASSY.	<u>563</u>	Mechanism Parts	1
1279699	PAPER GUIDE, FRONT, SUPPORT	564	Mechanism Parts	1
1423432	SHEET,POROUS PAD,PROTECT		Mechanism Parts	1
1410702	POROUS PAD,INK EJECT,RIGHT,UPPER	<u>580</u> <u>581</u>	Mechanism Parts	1
1410702	POROUS PAD, INK EJECT, RIGHT, OFFER POROUS PAD, INK EJECT, RIGHT, MIDDLE	582	Mechanism Parts	1
1410698	POROUS PAD, INK EJECT, RIGHT, MIDDLE POROUS PAD, INK EJECT, RIGHT, LOWER		Mechanism Parts	1
1404059	POROUS PAD, INK EJECT, RIGHT, LOWER POROUS PAD, CAP, LOWER	583 584	Mechanism Parts	1
	POROUS PAD, CAP, LOWER POROUS PAD, INK EJECT, MIDDLE		Mechanism Parts	2
<u>1410697</u>	POROUS PAD, INK EJECT, MIDDLE POROUS PAD, INK EJECT, LEFT, UPPER	<u>585</u>	Mechanism Parts	1
1410699		<u>586</u>		
1410696	POROUS PAD,INK EJECT,LEFT,LOWER	<u>587</u>	Mechanism Parts	1
1421324	LABEL,FRAME,MAIN	591 NONEIC	Mechanism Parts	1
1080614	GREASE G-26 (40GR)(B702600001)	NONFIG		1
1304682	GREASE G-71	NONFIG		1
1409257	GREASE G74	NONFIG		1
6022798	Shipping Cleaning Liquid,CR02,18kg	NONFIG		1
6022805	Shipping Cleaning Liquid,CR02,1kg	NONFIG	I OOIS	1

Part Code Part Name Ref No. Category Qty Remark